



How to install our Paddle Shifters on:

2010-2011 Chevrolet Camaro / 2008-2013 Cadillac CTS / CTS-V

Installation Instructions:

1 - Using a small flat screw driver, you will need to remove the existing plastic buttons by prying slowly right in between the plastic housing and the moving buttons.

(Please make sure you use a small flat screw driver to avoid scratching the plastic housing)

2 - Please check your existing buttons if they have some padding inside, if they do, use it by placing it inside the new extended paddles.

3 - Now you need to spray the 2 little hinges sticking out from your new extended paddles with some lubricant (WD-40 or a very small amount of grease), this will all the new Paddles to move freely once installed.

4 - Make sure you insert one of either hinges all the way in, using a small flat screw driver, you need to push away the plastic housing and slowly inserting the other side hinge without scratching the housing.

5 - You may hear a click or you may not, just make sure the paddle is well seated, that both hinges are in before start using them.

6 - Repeat the same process above on the other side and you're all set !

It is normal for the paddles to feel a little bit tight the first times you use them.

Any questions, feel free to contact one of our representatives for further assistance

Tel: 201 708 7017 - Email: sales@vitesse-motorsports.com